

Digital Concrete Test Hammer

HT-225V Instruction Manual



INDEX

One Summary	2
1 Introduction.....	2
2 Technical feature	2
3 Technical specification.....	3
4 Packing list.....	4
Two Operation Instructions	4
1 Outlooks.....	4
2 Switch on	5
3 Operation introduction	5
Three Software set	10
1 Installation of software	10
2 Software operation	12
Four Notice	13
Five Customer service	14
1 Product warranty	14
2 Product maintenance	14
3 Product and software update	14

One Summary

1 Introduction

Model HT-225V test hammer, with digital display and voice function, is invented by our company. Submit to the standards < Technical Specification of Inspecting Concrete Compressive Strength by Rebound Method > (JGJ/T23-2001) of the People's Republic of China, is a high-tech product especially designed for the needs of in place test for concrete compressive strength, applied to non-destructive testing (NDT) for all kinds of concrete compressive strength component in construct projects..

HT-225V Test Hammers for the quick and easy determination of the strength of concrete, and hardness of construction materials. Digital and voice functions allow greater number of test, leading to better quality tests. It's a good and useful instrument for quality control and inspection organizations.

2 Technical features

- 1) Submit to < Technical Specification of Inspecting Concrete Compressive Strength by Rebound Method > (JGJ/T23-2001).
- 2) Innovative integrated structure of the test hammer host and the display part. Easy to carry and make work efficient.
- 3) Taking the lead in using color LCD, 176x220 resolutions, English interface and friendly operation.
- 4) Friendly voice report service, don't have to watch the screen and improve test work efficiency
- 5) Adopting non-contact reflection grating sensor, maximum avoid machine attrition and poor contact in traditional technologies such as contact way or potentiometer way, and born with high precision, long service life, and keep the traditional rider scale.
- 6) High capacity rechargeable lithium battery, environmental protection, economical. Better than one time use alkaline cell.
- 7) The ability of connection with wireless portable printer, we can print test report in site immediately.
- 8) Big data storage capacity, more than 200 standard components, a standard component

Instruction of HT-225V Concrete Test Hammer

including almost 99 test areas, one test areas including 16 test points, completely meet the request of long time in site test.

9) Planted with unified national standard curve (China) as out of factory, and you can add more curve as per your region character if necessary. Max up to 20 measuring curves.

10) Testing parameters can be typed in as per characters in site, and test values will be calculated automatically.

11) Abnormal value auto-delete functions in case mistake operation. User can set limits.

12) Adopting USB interface, as U flash disk, no need special driver; able to upload and download test data and update test curves. (it's different from **【Communication】**).

13) Have real-time clock calendar function, can automatically record test date.

14) Advanced low power consumption function, can set display backlight level, voice volume, auto dormancy, and automatic turn off.

3 Technical specifications

1) Data processing standard: Submit to < Technical Specification of Inspecting Concrete Compressive Strength by Rebound Method > (JGJ/T23-2001).

2) Standard impact energy: 2.207J

3) Tension spring stiffness: 785 N/m

4) Stroke of impact hammer: 75 mm

5) Test value when calibrated on steel anvil (qualified anvil like type JW225): 80 ± 2

6) Bounds on error: $\leq \pm 0.5$ (the differences between display and rider)

7) Display screen: 16bit True colors, 176 x 220 resolution, 5 levels of backlighting adjustable.

8) Data storage capacity: 200 standard components (99 test areas per component), can be planted in 20 special measuring curves

9) Power: 3.6 V / 1300mAH lithium batteries, matching charging adapter 5V / 2A.

10) Power consumption: about 100mA (with maximum back lighting level and no voice function)

11) Communication port with PC: USB2.0

12). Net Weight: ≈ 1.1 Kg

Instruction of HT-225V Concrete Test Hammer


4 Packing list

Model HT-225V

No.	Name	units	Qty	Remarks
1	HT-225V test hammer special carrying case	pc	1	
2	HT-225V test hammer	unit	1	
3	USB communication cable	pc	1	
4	Charger of test hammer	pc	1	
5	Manual	booklet	1	
6	Software disc	pc	1	with box
7	<i>Wireless portable printer</i>	Pc	1	<i>selectable</i>
8	<i>Charger of printer</i>	Pc	1	<i>selectable</i>


Two Operation Instructions

1. Appearance



2. Open

Keeping press the **POW** key (red color) will get into welcome interface. (If the battery was exhausted completely before, internal clock needs to be reset, a dialog window will appear automatically for time setting.



3. Directions

During operation, if no any indication in the screen, the **POW** key defaults as return or cancel, **OK** key defaults as confirm key.

Menu and functions as followings:

【Sampling】 : Enter parameter settings interface, setting parameters for new component and start testing operation.

【View data】 : Review or delete the tested component data.

【Setting】 : Function and system setting

【Communication】: Only by choosing this button we can connect test hammer with manage system. **Remark: this function can download the test data from the machine. And the file is editable. files by U flash disk mode can not be edited.**

【Shut down】 : Turn off the instrument by software against manually shutdown by keeping pressing the **POW** key.


1). **【Sampling】**

Instruction of HT-225V Concrete Test Hammer

Choosing **【Sampling】** from the main menu, press the **OK** key to enter **【Parameter】** setting interface for new test component, such as the pumping markers, measuring curve and input way of carbonation depth.

Component number is auto-generated by the instrument.

- Pumping marker: use left and right key to choose. Pumped concrete choose “YES”
- Measuring curve: set and choose a suitable curve.
- Carbonation depth: set carbonation depth input mode.
- **【Sampling】** : click it and press **OK** key into **【Sampling】** interface.




Enter **【Sampling】** interface to begin measuring, if need set impact surface and impact angle and carbonation depth of the test area, choose **Set** and the parameter interface will appear. We can set test area parameter, change parameter or delete test values in it.



- **【Carb.Depth】**: press **OK** key into the carbonation depth interface, press up and down key to choose testing area, then press **OK** for confirmation, the screen will auto turn to the carbonation depth input interface, press left and right key to choose carbonation depth value, press **OK** for confirmation. Under average data model (incomplete carb-depth values allowed but should cover no less than 30% test area), if the difference between carbonation depth values more than 2mm, the instrument will warn and ask user choose Carbonation depth type-in mode by all (each test area needs depth value). But operator can neglect this by press **exit** key and modify carbonation depth value timely, or the instrument will continue to warn and require choose mode.

- **【Calculate】** : After a component sampling, press **OK** key for test data calculation. By press Save key to save sampling data and calculated results (extension index of the file is **cmp**), and automatically enter into next component test interface. Press **Back** key will not save and continue test the current component.



- **【Save Component】** : Save a temp file without calculation, extension name is (.tmp).
- **【Quit】** : Turn to the main menu.

2). **【View Data】**

Reviewing the existing component data in instrument, by press up and down key to



choose one component, **OK** key to show component data, **Detail** key to check details.



In the interface, press **Option** key can perform some operation.

- Add Data: press **OK** key to enter **【Parameter】** interface, add testing area data or change parameters for the test component.

Instruction of HT-225V Concrete Test Hammer

- Del Component: delete the current test component.
- Delete all the components: delete all data of test components saved in the instrument.
- Print: print the component data by portable printer. Aim the instrument infrared LPT at the infrared interface of printer, which must within a distance of less than 0.8 meters, beyond the distance printing will be failure.
- Quit: back to the main menu.

3). 【Setting】



- Lower Limit: set lower limit of abnormal values.
- Upper Limit: set upper limit of abnormal values.
- Backlight: set display backlighting brightness, 5 levels total, turn down the backlighting level can increase instrument using time.
- Volume: set up volumes of voice service and pressing keys. 4 level volumes total, reducing the volume of the instrument can increase using time.
- Auto Off: can set instrument automatic turn off time, if keep instrument out of operation, this set will begin works, and the display will auto shut down once it reach the time we set. So that avoid power consumption. (**don't worry, when display screen is on test interface during sampling, this set will out of work**)
- Sensor Adjust: if there is deviation between the display and mechanical pointer, or after changing any mechanical part of rebound hammer, calibration of the sensor's zero

Instruction of HT-225V Concrete Test Hammer

point is strong proposed. When calibrating on the steel anvil, we can adjust the display value as per the pointer by left and right keys, till they are always same. Then press **Save** to save the adjustment, or press **Back** key return to **【Setting】** interface without save.

- Setting Time: adjusting internal real-time clock.
- Product Info: can review relating information for the instrument; item NO, serial number, inspecting number, memory capacity and total test amounts information etc.

4). **【Communication】**



This function is that take the instrument memory as a virtual USB disk, computer can upload or download components data and measuring curve data, do not have to install driver.



5) **【Shut Down】** Instrument soft power-off against press constantly on/off key (red)to hard turn off.

Three The software


1. Installation software

Insert into software disk and install follow instruction.

Instruction of HT-225V Concrete Test Hammer




Instruction of HT-225V Concrete Test Hammer



2. Software Operation

Software operation Interface as follows:



Menu column

Project Information

Component Parameters

Component List

Test area number

Test data

Component Name	Date	Test Area Number
1	00	00
2	00	00
3	00	00
4	00	00
5	00	00
6	00	00
7	00	00
8	00	00
9	00	00
10	00	00
11	00	00
12	00	00
13	00	00
14	00	00
15	00	00
16	00	00
17	00	00
18	00	00
19	00	00
20	00	00
21	00	00
22	00	00
23	00	00
24	00	00
25	00	00
26	00	00
27	00	00
28	00	00
29	00	00
30	00	00
31	00	00
32	00	00
33	00	00
34	00	00
35	00	00
36	00	00
37	00	00
38	00	00
39	00	00
40	00	00
41	00	00
42	00	00
43	00	00
44	00	00
45	00	00
46	00	00
47	00	00
48	00	00
49	00	00
50	00	00
51	00	00
52	00	00
53	00	00
54	00	00
55	00	00
56	00	00
57	00	00
58	00	00
59	00	00
60	00	00
61	00	00
62	00	00
63	00	00
64	00	00
65	00	00
66	00	00
67	00	00
68	00	00
69	00	00
70	00	00
71	00	00
72	00	00
73	00	00
74	00	00
75	00	00
76	00	00
77	00	00
78	00	00
79	00	00
80	00	00
81	00	00
82	00	00
83	00	00
84	00	00
85	00	00
86	00	00
87	00	00
88	00	00
89	00	00
90	00	00
91	00	00
92	00	00
93	00	00
94	00	00
95	00	00
96	00	00
97	00	00
98	00	00
99	00	00
100	00	00
101	00	00
102	00	00
103	00	00
104	00	00
105	00	00
106	00	00
107	00	00
108	00	00
109	00	00
110	00	00
111	00	00
112	00	00
113	00	00
114	00	00
115	00	00
116	00	00
117	00	00
118	00	00
119	00	00
120	00	00
121	00	00
122	00	00
123	00	00
124	00	00
125	00	00
126	00	00
127	00	00
128	00	00
129	00	00
130	00	00
131	00	00
132	00	00
133	00	00
134	00	00
135	00	00
136	00	00
137	00	00
138	00	00
139	00	00
140	00	00
141	00	00
142	00	00
143	00	00
144	00	00
145	00	00
146	00	00
147	00	00
148	00	00
149	00	00
150	00	00
151	00	00
152	00	00
153	00	00
154	00	00
155	00	00
156	00	00
157	00	00
158	00	00
159	00	00
160	00	00
161	00	00
162	00	00
163	00	00
164	00	00
165	00	00
166	00	00
167	00	00
168	00	00
169	00	00
170	00	00
171	00	00
172	00	00
173	00	00
174	00	00
175	00	00
176	00	00
177	00	00
178	00	00
179	00	00
180	00	00
181	00	00
182	00	00
183	00	00
184	00	00
185	00	00
186	00	00
187	00	00
188	00	00
189	00	00
190	00	00
191	00	00
192	00	00
193	00	00
194	00	00
195	00	00
196	00	00
197	00	00
198	00	00
199	00	00
200	00	00
201	00	00
202	00	00
203	00	00
204	00	00
205	00	00
206	00	00
207	00	00
208	00	00
209	00	00
210	00	00
211	00	00
212	00	00
213	00	00
214	00	00
215	00	00
216	00	00
217	00	00
218	00	00
219	00	00
220	00	00
221	00	00
222	00	00
223	00	00
224	00	00
225	00	00
226	00	00
227	00	00
228	00	00
229	00	00
230	00	00
231	00	00
232	00	00
233	00	00
234	00	00
235	00	00
236	00	00
237	00	00
238	00	00
239	00	00
240	00	00
241	00	00
242	00	00
243	00	00
244	00	00
245	00	00
246	00	00
247	00	00
248	00	00
249	00	00
250	00	00
251	00	00
252	00	00
253	00	00
254	00	00
255	00	00
256	00	00
257	00	00
258	00	00
259	00	00
260	00	00
261	00	00
262	00	00
263	00	00
264	00	00
265	00	00
266	00	00
267	00	00
268	00	00
269	00	00
270	00	00
271	00	00
272	00	00
273	00	00
274	00	00
275	00	00
276	00	00
277	00	00
278	00	00
279	00	00
280	00	00
281	00	00
282	00	00
283	00	00
284	00	00
285	00	00
286	00	00
287	00	00
288	00	00
289	00	00
290	00	00
291	00	00
292	00	00
293	00	00
294	00	00
295	00	00
296	00	00
297	00	00
298	00	00
299	00	00
300	00	00
301	00	00
302	00	00
303	00	00
304	00	00
305	00	00
306	00	00
307	00	00
308	00	00
309	00	00
310	00	00
311	00	00
312	00	00
313	00	00
314	00	00
315	00	00
316	00	00
317	00	00
318	00	00
319	00	00
320	00	00
321	00	00
322	00	00
323	00	00
324	00	00
325	00	00
326	00	00
327	00	00
328	00	00
329	00	00
330	00	00
331	00	00
332	00	00
333	00	00
334	00	00
335	00	00
336	00	00
337	00	00
338	00	00
339	00	00
340	00	00
341	00	00
342	00	00
343	00	00
344	00	00
345	00	00
346	00	00
347	00	00
348	00	00
349	00	00
350	00	00
351	00	00
352	00	00
353	00	00
354	00	00
355	00	00
356	00	00
357	00	00
358	00	00
359	00	00
360	00	00
361	00	00
362	00	00
363	00	00
364	00	00
365	00	00
366	00	00
367	00	00
368	00	00
369	00	00
370	00	00
371	00	00
372	00	00
373	00	00
374	00	00
375	00	00
376	00	00
377	00	00
378	00	00
379	00	00
380	00	00
381	00	00
382	00	00
383	00	00
384	00	00
385	00	00
386	00	00
387	00	00
388	00	00
389	00	00
390	00	00
391	00	00
392	00	00
393	00	00
394	00	00
395	00	00
396	00	00
397	00	00
398	00	00
399	00	00
400	00	00
401	00	00
402	00	00
403	00	00
404	00	00
405	00	00
406	00	00
407	00	00
408	00	00
409	00	00
410	00	00
411	00	00
412	00	00</td

1). New project files

By clicking [new] in [file] menu, we can create a new file.

2) Open engineering documents

By clicking [open] in [file] menu, we can open a existing file.

3) Import components data



Right click the component list, appear dialog window, choose import component, we can upload component date in computer or test hammer (test hammer has been connected with computer). Component data will be shown in component parameters column, and we can edit component information here.

4) Delete component data

Right click on a component data which need to be deleted in component list, appear the same dialog window as above, and choose delete component, the component data will be removed from project files.

5) Print

After editing and modification, we can print data by clicking [print] in [file] menu.

Four Notice

When processing the test values by instrument and software, as data accuracy limitations and the algorithm rounding, results may has deviation from that by hand, if the deviation affects the inspecting conclusion, then the calculation results by hand shall be the first choose.

This instrument belongs to the precision electronic instrument; it should be used and stored carefully. It should be protected from impact, fall, high temperature, or immersed in water, and avoid being used in a strong magnetic environment. Any of above situation unfortunately occurred and caused any damage or out of work, please turn off immediately and contact with distributor or manufacturer.

Please use the original matched adapter for battery charger, others may be dangerous.

Instruction of HT-225V Concrete Test Hammer

Battery life may be reduced by overcharging. When battery charging complete, indicating light will turn to green from red, and should stop charging immediately. It is proposed that some one should supervise the charging process.

When it shows lower battery capacity, we can extend use time by shut down voice report and turn down backlight class.

During practical test, should keep appropriate operation frequency, test interval shouldn't less than 1 second, so that keep good accuracy of test values.

Customer Services

1. Product warranty

Product warranty period is for one year, but following situations are excepted:

- 1) Instruments and accessories got severe damage because of irregular operation, such as impact, fall, water or high temperature scorching etc.
- 2) The circuit board was detached, changed by user.
- 3) Battery or inside circuit get damaged because of unqualified charger.
- 4) Other exception cases.

2. Product maintenance

Our company promises perpetually maintain service for HT-225V and its component. Mechanical part and its accessories can get paid maintain service. Following cost need to be taken by customer.

- 1) Transportation charge for the instrument.
- 2) And travel expense and accommodation fee if customer need our engineers go to any appointed place. This cost only charge for one day.
- 3) Direct costs for component changed; extra service costs for these parts without free repair service.

3. Products and software upgrades

If necessary our company will upgrade software for HT-225V test hammer, details please